


Bedienungsanleitung VX33E19R

3-Zeiger / Tag / Datum



KRONENSTELLUNGEN			
	Stellung N - Normalposition	Stellung 1 - Einstellung des DATUMS und WOCHENTAG	Stellung 2 - Einstellung der ZEIT
Krone	Krone gegen das Uhrgehäuse gedrückt	Krone gegen den Uhrzeigersinn drehen	Drehen Sie die Krone in eine beliebige Richtung

❖ EINSTELLEN DER UHRZEIT

1. Ziehen Sie die Krone auf die Position 2 heraus wenn der Sekundenzeiger bei 12 ist.
2. Drehen Sie die Krone im Uhrzeigersinn, um die Zeit einzustellen.

HINWEIS: Der Minutenzeiger muss zum Einstellen 4 bis 5 Minuten weiter als die Uhrzeit sein und dann zurück auf die genaue Minute gedreht werden.

3. Drücken Sie die Krone wieder in die Position N zurück.

❖ EINSTELLEN DES DATUMS UND DES WOCHENTAGES

1. Ziehen Sie die Krone auf die Position 1 heraus.
2. Die Krone entgegen dem Uhrzeigersinn drehen, um das Datum einzustellen und in den Uhrzeigersinn drehen für die Einstellung des WOCHENTAGES.

VORSICHT: Stellen Sie das Datum nie ein, wenn sich die Zeiger zwischen 9:00 Uhr abends und 3:00 Uhr morgens befinden. Andernfalls kann dies zur Beschädigung des Kalendermechanismus führen.

3. Drücken Sie die Krone wieder in die Position N zurück.


❖ **BATTERIEWECHSEL-FRÜHANZEIGE**

Die Uhren mit Sekundenzeiger haben eine Batteriewechsel-Frühanzeige, d.h.: Ca. 1 Woche bevor die Batterie gewechselt werden muss, wird dieses durch ein optisches Signal angezeigt: Der Sekundenzeiger bewegt sich im 2 Sekundenrhythmus. Die Zeitgenauigkeit bleibt jedoch erhalten. Lassen Sie dann umgehend die Batterie fachmännisch ersetzen!

Instruction of Watch Movement

3 hands / Day / Date

◆ Display



◆ Crown operation

	Crown position		
	N : normal	1 : 1st click	2 : 2nd click
Crown	Free	<ul style="list-style-type: none"> •Turn counterclockwise for date change •Turn clockwise for day of the week change 	Time setting

◆ How to set time

- (1) Pull the crown out to the 2nd click position when the second hand is at the 12 o'clock position.
- (2) Turn the crown to set the hour and minute hands.
Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.
 - When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.
- (3) Push the crown back to the normal position.

◆ How to set date and day of the week

- (1) Pull the crown out to the 1st click position.
- (2) Turn the crown to set the date and the day of the week.
 - Do not set the date and day of the week between 9:00 p.m. and 4:00 a.m..
- (3) Push the crown back to the normal position.

Tips : When the date and the day of the week changes during daytime, it happens when a.m./p.m. is wrongly set.
Advance the hour hand by 12 hours.

◆ Power depletion warning function

When the battery nears its end, the second hand moves at two-second intervals instead of the normal one-second intervals. In that case, have the battery replaced with a new one as soon as possible.

- The watch remains accurate while the second hand is moving at two-second intervals.

Note : The availability of this function is different depending on the caliber.